

What does the red **TC** indication mean ... ? (Top right of the touch screen).

The red **TC** indication lights when the timecode reader cannot detect timecode or is the timecode is not valid.

<u>Condition</u>	<u>TC Warning Indication</u>
No Timecode to TC reader	ON
Timecode not moving	ON
Timecode frame rate mis-match	Flashes
Timecode jumps - discontinuous TC	Flashes at jumps
TC input at non-standard speed	Flashes
Valid contiguous Timecode	OFF